



REFERENCE NOTES:

- ① MOUNT ON UNSECURED SIDE OF DOOR("OUTSIDE")
- ② MOUNT ON SECURED SIDE OF DOOR("INSIDE")
- ③ MOUNT ABOVE DROPPED CEILING ON SECURED SIDE OF DOOR. IF CEILING IS NOT REMOVABLE, INSTALL ACCESS PANEL TO REACH BOX FOR MAINTENANCE.
- ④ MOUNT IN TWO GANG BOX FLUSH BOX, UNLESS NOTED OTHERWISE

GENERAL NOTES:

1. SEE RISER DIAGRAM FOR CABLING REQUIREMENTS
2. ALL WIRING TO BE IN RACEWAY USING FLEX, OR EMT, AS APROPRIATE. ALL RACEWYAS TO BE RECESSED UNLESS NOTED OTHERWISE. EXACT RACEWAY ROUTING BY FIELD.
3. IF DOOR HAS POWER ASSIST, HOLD OPENS OR ANY OTHER SPECIAL FEATURES SEE UNIVERSITY ENGINEER FOR ADDITIONAL DETAILS TO ACCOMODATE FEATURES.
4. CAREFULLY COORDINATE DOOR HARDWARE, BEFORE PURCHASING OR INSTALLING, TO INSURE COMPATIBILITY WITH DOOR AND FRAME.
5. ELECTRIC POWER TRANSFER(EPT) AND ELECTRIC (ES) TO BE INSTALLED BY EXPERIENCED DOOR HARDWARE PERSONNEL ONLY.

DOUBLE DOOR WITH ELECTRIC STRIKE

NO SCALE